



Winter Cover Braces: Both fabricated of 2 X 6 lumber. A simple "V" can be cut in place of the circular notch. The longer brace supports the boom, the shorter the spinnaker pole. Use dry wall screws to attach a "T" support to the base of the boom support. A 2X 4 can also be used for the pole support.

